

K3 KIT ASSEMBLY MANUAL ERRATA

Rev. L8-1, February 25, 2013

YOU NEED TO MAKE THESE CHANGES TO YOUR MANUAL ONLY IF YOU HAVE THE K3EXREF OPTION TO INSTALL WHILE ASSEMBLING YOUR K3 KIT.

1. Page 25, Figure 30, Add Note:

Do not install a plug in the hole marked REF if you have the K3EXREF option.

2. Page 44, add the following immediately after Figure 64:

If you are installing the K3EXREF option, refer to the *K3 K3EXREF Frequency Lock Option* manual and install the coaxial cable as shown in Figures 3, 4 and 5 on pages 7 and 8. Note that in your kit the K3's bottom cover and KREF3 board are not yet installed. They will be added later.

3. Page 47, at the bottom of the page after the second check box step add:

If you are installing the K3EXREF option, mount the K3EXREF board on the KREF3 board as shown in the *K3 K3EXREF Frequency Lock Option* manual, Figures 8 and 9 (pages 9 and 10). Be sure to install the shorting block as shown in Figure 8. After the KREF3 board is in place, be sure to connect the TMP connector on the cable you installed earlier to the connector that passes through the front panel shield.

4. Page 67, Reference Oscillator Calibration, add to the existing text:

If you stalled the K3EXREF option, refer to *Using the K3EXREF* on page 4 of the *K3 K3EXREF Frequency Lock Option* manual for testing and operating instructions.