

KXB30 MANUAL ERRATA

Rev. A-1, Oct. 28, 2003

**THESE MANUAL CORRECTIONS MUST BE MADE
BEFORE YOU BEGIN ASSEMBLY.**

1. **Page 5:** In the third step, change *insulted* to *insulated*¹.
2. **Page 5:** The last step on this page should be replaced with the following (cut out the paragraph and tape it over the original):
 - Insert the four 1" (2.5 cm) bare wires into the *G*, *C*, *A*, and *G* pads along the edge of the KXB30 board, from the *top* side. Insert the 1.5" (4 cm) bare wire into the *B* pad. Before soldering, make sure almost the entire length of each wire is extending out from the top side—the wires should be inserted all way into their respective holes, but no farther.

¹ Elecraft has a policy of not verbally abusing hookup wire.