

ELECRAFT K3 OWNER'S MANUAL ERRATA

Rev. D10-1, August 25, 2011

CAUTION REGARDING THE EXTERNAL SPEAKER JACK: This jack is stereo, not mono, because of the K3's stereo speaker outputs. If you use a mono speaker plug, turn off the right channel amplifier by setting the SPKRS configuration menu entry to 1. This will eliminate the possibility of damaging the right-channel amplifier. (You will still hear stereo when using headphones in this case, unless you also set the SPKR+PHones menu entry to YES.)

See http://www.elecraft.com/K3/k3_software.htm for firmware release notes and update instructions.