

# ELECRAFT PX3 PROGRAMMER'S REFERENCE

Rev. A1 (See Appendix A for change history)

## Command Set Overview

The PX3 provides a set of remote-control commands to control the most important instrument functions (Table 1). Details on individual commands start on page 2.

**Table 1.** PX3 Control Commands.

Name	Description	Name	Description	Name	Description
=	Product ID	#FNL	Function key label	#OSBA	OSB Amplitude
#AVG	Averaging time	#FNX	Function key execute	#OSBP	OSB Phase
#BMP	Bitmap upload	#FXA	Fixed auto-adjust mode	#PKM	Peak mode on/off
BR	Baud rate set	#FXT	Fixed or Tracking select	#PS	Power status/control
#BR	Baud rate set	#LBL	Labels on/off	#PT	Pass-Through mode
#CAL	Calibration signal on/off	#LD	Internal use only	#QSY	QSY to current marker
#CTF	Center frequency	#MFA	Marker A frequency	#REF	Reference Level
#DSM	Display mode	#MFB	Marker B frequency	#RST	Reset the PX3
#ER	Internal use only	#MKA	Marker A on/off	#RVM	Main firmware revision
#EW	Internal use only	#MKB	Marker B on/off	#SCL	Scale
#EXR	Internal use only	#NB	Noise blanker on/off	#SPN	Span
#EXW	Internal use only	#NBL	Noise blanker Level	#VFB	VFO B cursor on/off

The **Command Tester** screen of the *PX3 Utility* computer program is a convenient way to try individual control commands. You can also define macros, which allow sending strings of PX3 and/or KX3 commands with a single mouse click. The **Capture Image** screen uses the **#BMP** command to upload the current PX3 screen to a standard bitmap graphics file. See the *PX3 Utility* help facility for details.

When a KX3 is connected to the RS232 "ACC1 XCVR" port, both KX3 and PX3 commands can be sent from the same computer program. For example, **#RVM;** returns the revision number of PX3 firmware and **RVM;** returns the revision number of main firmware in the KX3. Sending those two commands is a handy way to check the connectivity of the two RS232 ports on the PX3. If you get a response to **#RVM;** then the PC port is connected; if you get a response to **RVM;** then the XCVR port is connected as well.

### Command Format

Commands sent from the computer to the PX3 are considered either GETs or SETs. GET commands are used by the computer to get information from the PX3; the PX3 will then provide an appropriate response message (RSP). SET commands are sent by the computer to change the instrument's configuration or initiate an event. Commands with an incorrect format or an out-of-range parameter are ignored. A SET can be followed by a GET to verify the new settings.

SET commands use 2-4 characters, optional data fields, and a terminating semicolon (;). Examples:

**#AVG05;**      Computer turns on averaging with a time constant of 5.  
**#DSM1;**      Computer selects spectrum+waterfall display mode.

Many SET commands have a corresponding GET command, which is just the command letters with no data, plus the semicolon. The data format of the response message from the PX3 (RSP) is usually identical to the format of the SET data. Exceptions are noted in the command descriptions.

Characters sent to the PX3 can be in either upper or lower case. The PX3 always responds with upper case.

## Command Reference

This section describes all PX3 GET, SET and RSP (response) command formats. Unless otherwise noted, the GET format is just the 2 or 3 letters of the command followed by a semicolon. The SET and RSP data formats are identical unless otherwise noted. All commands must be followed by a semicolon except where noted.

= (*Product identification; GET only*)

RSP format: **PX3** (main firmware executing) or **px3** (boot loader ready to download new firmware). There is no "#" or semicolon in either the query or the response.

**#AVG** (*Averaging Time, GET/SET*)

SET/RSP format: **#AVGnn**; where **nn** is 00 (average mode off) or the averaging time constant, 02-20 (average mode on).

**#BMP** (*Bitmap upload, GET only*)

RSP format: **[bmp]cc** where **[bmp]** is 131,638 bytes of binary image data in standard .BMP file format and **cc** is a two-byte checksum. Note that the response does not include the command name and has no terminating semicolon. The checksum is the modulo-65,536 sum of all 131,638 bytes, sent least-significant byte first.

**BR and #BR** (*Baud Rate of the PC RS232 port, SET only*)

SET format: **BRn**; or **#BRn**; where n is **0** (4800 b), **1** (9600 b), **2** (19200 b), or **3** (38400 b). The *PX3 Utility* program automatically sets the PX3 to 38400 baud for downloads, then restores the baud rate to the user's selection (that was made using either this command or the PX3's RS232 menu entry). Note that the RS232 port that connects to the KX3 always runs at 38400 baud. Any **BR** command that is received from a host computer affects the baud rate of the PX3 (on the RS232 port that connects to the PC), not the KX3.

***#CAL (Calibration signal on/off, GET/SET)***

SET/RSP format: **#CALn**; where **n** is **0** (calibration signal off) or **1** (calibration signal on). The calibration signal generated is based on the current KX3 band.

***#CTF (Center Frequency, GET/SET)***

SET/RSP format: **#CTFsxxxxxxxx**; where **s** is +/- and **xxxxxxxx** is the center frequency in Hz. **s** can also be a space in lieu of +. Example: **#CTF+0001406000**; sets the center frequency to 14060 kHz. If the specified frequency is outside the range the PX3 can tune to, the action is undefined. A value of zero sets the center frequency to the main VFO frequency of the transceiver. For transceivers other than the KX3, the center frequency is interpreted relative to the frequency the transceiver is tuned to and may be positive or negative.

***#DSM (Display Mode, GET/SET)***

SET/RSP format: **#DSMn**; where **n** is **0** (spectrum only) or **1** (spectrum + waterfall).

***#FNL (Function Key Label, GET only)***

GET format: **#FNLn**; where **n** = 1-8, for keys FN1-FN8.

RSP format: **#FNLcccccccc**; where **n** = 1-8 and **cccccccc** are the 9 ASCII characters in the key label for FNn.

***#FNX (Function Key Execute, SET only)***

SET format: **#FNXn**; where **n** = 1-8, for keys FN1-FN8. Executes the function assigned to the key, if any.

***#FXA (Fixed-tune Auto-adjust Mode, GET/SET)***

SET/RSP format: **#FXAn**; where **n** is **0** (Full screen), **1** (Half screen), **2** (Slide) or **3** (Static) to specify how far the PX3 center frequency moves when the KX3 VFO A is tuned off screen in fixed-tune mode.

***#FXT (Fixed or Tracking Select, GET/SET)***

SET/RSP format: **#FXTn**; where **n** is **0** (Tracking mode), or **1** (Fixed-tune mode).

***#LBL (Labels on/off, GET/SET)***

SET/RSP format: **#LBLn**; where **n** is **0** (FN key labels off), **1** (FN key labels on) or **2** (text decode on).

**#MFA, #MFB (Marker A/B Frequency, GET/SET)**

SET/RSP format: **#MFA**sxxxxxxxxxxx; or **#MFB**sxxxxxxxxxxx; where **s** is +/- and xxxxxxxxxxxx is the marker frequency in Hz. **s** can also be a space in lieu of +. Example: **#MFA+00014060000**; sets the marker A frequency to 14060 kHz. If the specified frequency is in a different band than the KX3 is tuned to, the action is undefined. A value of zero sets the marker to the main VFO frequency of the transceiver. For transceivers other than the KX3, the marker frequency is interpreted relative to the frequency the transceiver is tuned to and may be positive or negative.

**#MKA, MKB (Marker A/B on/off, GET/SET)**

SET/RSP format: **#MKAn**; or **#MKBn**; where **n** is **0** (marker off) or **1** (marker on). The last marker to be turned on automatically becomes the active marker, meaning it can be adjusted with the knob and is the one that responds to the QSY command. If the marker was off-screen before executing a marker-on command, it will default to the center frequency.

**#NB (Noise blanker on/off, GET/SET)**

SET/RSP format: **#NBn**; where **n** is **0** (noise blanker off) or **1** (noise blanker on).

**#NBL (Noise blanker level, GET/SET)**

SET/RSP format: **#NBLnn**; where **nn** sets the aggressiveness of the noise blanker algorithm, 1 = least aggressive, 15 = most aggressive.

**#OSBA (Opposite side band null amplitude value, GET/SET)**

SET/RSP format: **#OSBA**snnn; where **s** is the sign (+ or -) and **nnn** is the value. **s** can also be a space in lieu of +. Value range is -999 to +999. This is a per-band setting.

**#OSBP (Opposite side band null phase value, GET/SET)**

SET/RSP format: **#OSBP**snnnn; where **s** is the sign (+ or -) and **nnnn** is the value \* 10. **s** can also be a space in lieu of +. Value range is -450 (-45.0) to 450 (45.0). This is a per-band setting.

**#PKM (Peak Mode on/off, GET/SET)**

SET/RSP format: **#PKMn**; where **n** is **0** (peak mode off) or **1** (peak mode on).

**#PS (Power Status, GET/SET)**

SET/RSP format: **#PSn**; where **n = 1** indicates the PX3 is on. **#PS0** turns the PX3 off, but this removes power so **#PS1** cannot be used to turn it on. Note that if the power-on jumper on the rear-panel I/O board is in the "always on" position, then the **#PS0** command has no effect.

***#PT (Pass Through, SET only)***

SET format: **#PT**; Sets the PX3 to pass-through mode, that is, the panadapter operation ceases and all data received on either RS232 port is passed through immediately to the other RS232 port without delay or modification. This command is used by *PX3 Utility* when downloading new firmware to the KX3 transceiver. Pass-through mode ends automatically 20 seconds after the last RS232 activity.

***#QSY (QSY to current marker, SET only)***

SET format: **#QSYn**; where **n** is **1** (QSY) or **0** (undo QSY). "QSY" means the currently-active marker frequency is transferred to the associated VFO on the KX3. MKR A controls VFO A and MKR B controls VFO B. "Undo QSY" means to return the VFO to the frequency it was on before the last QSY, a one-level undo command.

***#REF (Reference Level, GET/SET)***

SET/RSP format: **#REFsnnn**; where **s** is +/- and **nnn** is the reference level in dBm, between -170 and +010 dBm. **s** can also be a space in lieu of +. For example, **#REF-120**; sets the reference level (at the bottom of the PX3 spectrum screen) to -120 dBm.

***#RST (Reset the PX3, SET only)***

Forces a power-on reset.

***#RVM (Main Firmware Revision, GET only)***

RSP format: **#RVMNN.NN**; where **NN.NN** is the firmware revision, e.g. **01.23**.

***#SCL (Scale, GET/SET)***

SET/RSP format: **#SCLnnn**; where **nnn** is the scale (the difference in dB between the top and bottom of the spectrum screen), between 010 and 080 dB. Example: **#SCL080**; sets the scale to 80 dB.

***#SPN (Span; GET/SET)***

SET/RSP format: **#SPNxxxxxx**; where **xxxxxx** is 000020-002000, the span in 100-Hz units. Example: **#SPN000500**; sets the span to 50 kHz.

***#VFB (VFO B cursor on/off; GET/SET)***

SET/RSP format: **#VFBn**; where **n** is **0** (VFO B cursor off) or **1** (VFO B cursor on).

**Appendix A: Change History** [Applicable firmware revision shown in brackets]

A1, 7-14-15 [01.25] Original